



Quick Reference Guide BOCR 2.0 Motor Protection Relay

Thank you for purchasing the BCH BOCR 2.0 Relay
This product is for product user & maintenance person

SAFETY PRECAUTIONS

Be sure to read the instruction manual and safety precautions before use products.

⚠ Warning : Offending against the message will result in death or serious injury.

⚠ Caution : Incorrect handling of the device may result in minor injury or physical damage.

Caution

- Change in setting is possible only in motor stop state and there should not be any fault with appropriate password. Default password is 1004.
- Keep the product in the place where is no humidity and dust.
- Please check the phase & polarity while inserting the CT wire.
- Wrong polarity or phase can cause the wrong result (may cause Phase Reversal / Unbalance / Earth Fault).
- The product which is different from order is may cause a malfunction or a fire.
- Installation, maintenance and inspection of the product should be performed by the qualified Engineers.
- In case of Single phase motor, Disable the function Phase Loss, Phase unbalance and Reverse Phase. Under current will not work.
- After every Trip acknowledge the relay with front RESET button.
- Wire the terminal after confirming the terminal number, It may cause the damage or fire.
- Recommended to use BCH supplied CBCT only.

Warning

- Do not change the setting during motor running.
- Turn off the upstream breaker before installing or service to prevent electric shocks & burn due to short circuit.



BCH Electric Limited

01

BOCR 2.0

Overview

The quick reference guide (QRG) takes you through the installation and setup of BOCR 2.0 series motor protection relays and helps user to get setup and running as quickly as possible. This guide contains only basic information to operate the relay.

General Description

BOCR 2.0 series motor protection relay is a micro controller based relay designed for protection of LV & MV motors. It is equipped with 3 output relays for trip and alarm. Following are the brief description:-

Parameter

Operational Current	0.8 - 8.0 x IFL / .06-10 x IFL
Frequency Range	50 / 60 Hz
Phase Current Measurement Accuracy	Accuracy : + 5% [0.2 - 6.0 x IFL (60A model) / 0.5 - 8.0 x IFL (5A model)]
Protection	Over-Load, Under-Current, Short Circuit, Lock Rotor, Stall, Unbalance, Phase Loss, Phase Reversal, Earth Fault, CB Failure
Accuracy	
Trip Time	± 5% (or + 100 mSec) (which ever is higher)
Trip Current (Phase)	± 5% (or + 0.020 Amp) (which ever is higher)
Trip Current (Earth)	± 5% (or + 0.020 Amp) (which ever is higher) - (CBCT model)

Display

7 Segment	Metering and Fault information
Bar Graph	65 - 100 % of IFL setting
LED	RUN: Flashing for Motor Start/ Steady for Motor Run TRIP: Flashing for Fault/ Pick up/ Steady for Trip K: kiloAmp, LED glows for Current > 999 Amp

Auxiliary Supply

Power Consumption	L: 110V AC (100-160V) / H: 220V AC (190-260V) / W: 85-450V AC Approx. 6W
Contact Rating	1 C/O Contact - N/O contact, 5A / 250V AC or 24V DC; N/C contact, 2A / 250V AC or 24V DC
DO Contact	2 N/O Contact with 1 common, 5A / 250V AC or 24V DC

CBCT Input

30 mA to 2 Amp: CT Ratio 1:1500
*Different ID available based on Ordering Information (Refer Catalog)

Relay Reset

Trip Relay (DO1) Reset: Manual/Auto
Alarm Relay (DO2 & DO3) Reset: Manual / Automatic

Thermal Reset

Enable (ON): Thermal memory <50% & Reset key pressed
Disable (OFF): Thermal memory 0% & Reset key pressed


Mounting

Temperature	35 mm Din-rail
Operation	0°C to 70°C
Storage	-10°C to 85°C

Wiring Connection

For current Penetration / Tunnel Type
For Others (Aux supply, Relay contact etc.) Screwed Terminal


Model Information



02

BOCR 2.0

Front Interface



It comprises of 7 Segment display :-



- Three Push buttons for setting and other operations for local access. one push button for fault acknowledgment/Reset.
- 1 LED for PICKUP/TRIP on fault, which require Manual reset through RESET key. 1 RUN LED for motor Start/Run indication.
- Motor State Indicator: Flashing of RUN LED for Motor Start & glowing steady of RUN LED for run condition.

Keys	Description
ENTER RESET	used as ENTER key in Edit / Setting / View menu Long Press for Fault Reset
↑	used as scroll key / increment key
↓	used as scroll key / decrement key

03

BOCR 2.0


Terminal Connection Details




04

BOCR 2.0


BOCR 2.0 with external CBCT for Earth fault detection



BOCR 2.0 with external Phase CT and external CBCT



BOCR 2.0 with External Phase CT & without CBCT



05

BOCR 2.0

Setting Parameters

Common Setting Parameters

Parameter	Display	Setting Range		Step Size	Unit	Default Setting
		Min.	Max.			
Full Load Current (IFL)	IFL	2.50 ⁽¹⁾ /0.25 ⁽¹⁾	60.00 ⁽²⁾ /5.00 ⁽¹⁾	0.01	Amp	60.00/5.00
Motor Start Time	Stt	1.0	200.0	1	Sec	8
CT Ratio	ECR	1	999	1	---	1
Auto IFL Detection ⁽³⁾	ROI	-	-	-	-	-

NOTE :

- ⁽¹⁾ 5A model.
- ⁽²⁾ 60A model.
- ⁽³⁾ User can set the Full Load current setting through HMI, as per his application requirement. However for the ease of installation, user can use this feature during installation to detect the Full load current itself by the BOCR 2.0. (Refer Page No. 12)

Protection Setting Parameters

Parameter	Display	Setting Range		Step Size	Unit	Default Setting
		Min.	Max.			
Over-load Pickup	OLd	50	150	5	% IFL (Amp)	110
Over-load Characteristics	OLC	definite	thermal	-	-	thermal
Trip Class	tcl	5	30	5	% IFL (Amp)	10
Short Circuit Pickup	SCP	200	1000 ⁽¹⁾	5	% IFL (Amp)	OFF
Under-load Pick up	UCP	20	90	5	% IFL (Amp)	OFF
Locked Rotor Pick up	LrP	200	1000 ⁽¹⁾	10	% IFL (Amp)	OFF
Phase Unbalance Pickup	PLC	5	100	5	% IFL (Amp)	OFF
Stall Rotor Pick up	SeL	150	800	5	% IFL (Amp)	OFF
Earth Fault Pickup	EFP	0.030	2.000	0.005	Amp	OFF

NOTE :

- All above protection are available with disable option (OFF).
- BOCR 2.0 will allow change in IFL setting only if motor is in stop condition and there is no fault pickup
- ⁽¹⁾ Earth Fault calculation using externally connected CBCT.
- Model dependent.
- 60A Model - 800%
- 5A Model - 1000%

06

BOCR 2.0

Advanced Setting Parameter

Parameter	Display	Setting Range		Step Size	Unit	Default Setting
		Min.	Max.			
Phase loss detection time	ELPL	0.50	5.00	0.01	sec	OFF
Phase Unbalance detection time	ELPU	1.00	30.00	0.01	sec	30.00
Locked Rotor detection time	ELR	0.10	5.00	0.01	sec	5.00
Stall detection time	ELST	0.50	10.00	0.01	sec	10.00
Under-load detection time	ELUC	1.00	30.00	0.01	sec	30.00
Short circuit detection time	ELSC	0.05	1.00	0.01	sec	1.00
Phase reversal time	ELPR	OFF	ON	-	-	OFF
Earth fault detection time	ELF	0.05	10.00	0.05	sec	10.00
Contact failure detection time	ELCF	0.10	10.00	0.10	sec	OFF
Overload definite time	ELDL	0.10	30.00	0.10	sec	30.00
Motor type(1Ph or 3 Ph)	PHL	1	3	-	-	3
"Auto Scroll"	RUS	OFF	ON	-	-	OFF
(Enable:ON /Disable:OFF)						
"Thermal Memory Reset"	rLH	OFF	ON	-	-	ON
(Enable:ON /Disable:OFF)						
"Trip Relay Fail Safe"	FSF	OFF	ON	-	-	OFF
(Enable:ON /Disable:OFF)						
"Alarm Relay Reset Option"	RLr	Ato	nul	-	-	nul
(Enable:ON /Disable:OFF)						

NOTE :

- Selecting motor type to 1 Ph then Phase loss, Unbalance, Under-load & Reversal function will not work.

07

BOCR 2.0

Current Range Selection

Model 1 (60 Amp)		Model 2 (5 Amp)		No.of times wire passes through Built-in CT
Phase CT selection	Rated Current Range	Phase CT selection	Rated Current Range	
nonE	2.5 - 60 Amp	nonE	0.25 to 5 Amp	Once
Ext CT	5 Amp	Ext CT	5 Amp	Once

BOCR 2.0 supports motor current above 60 Amp with external CT with rated secondary current of 5 Amp.

NOTE: BCH recommend to use Model-2, when using External CT.

Human Machine Interface



Navigation and editing of the HMI are performed by using the Scroll, Reset, and Enter keys to switch between screens



Main Screens




08








Full Load Current Auto Detection



User can set the Full Load current setting though HMI, as per his application requirement. However for the ease of installation, user can use this feature during installation to detect the Full load current itself by the BOCR. The steps are as below.



- Auto Full Load detection can lead to three states: Wait state, Success State or Fail State. . User Can see the Status message on the Home screen bottom page.
- Waiting State: If the Motor is in Start State, BOCR will display inject current at the screen. It will detect the IFL automatically when the motor change it states to Running state from Starting Phase.
- Auto IFL Detection Fail: If the current detected is not between 70% to 130% of the existing IFL (or the default IFL for the first use) then Auto IFL detection may end up with Failure return. It also show failure if there is any pickup or fault state.
- Auto IFL Detection Successful: If the full load current detected is within the range of 70% to 130% of the previously set Current and The motor is in Run condition (Motor LED is glowing steady, not blinking) and there is no pickup or fault detected then only the Auto IFL will be accepted successfully by the relay.



Annexure - A			
Fault Info	Description	Fault Info	Description
PhLS	Phase Loss	UnCU	Under Current
PhrL	Phase Reversal	OLad	Overload
PhUb	Phase Unbalance	Eath	Earth Fault
StaL	Stall	CbFL	Contacture Failure
Lkro	Locked Motor	SCKt	Short Circuit



Trip Test

In the case of a trip test, which is performed when the motor is in the stop condition, all the segments of the 7-segment display will start glowing one by one, all the LEDs will light up one by one, and all the relays will turn on and off sequentially.

Trouble Shooting Points

Problem	Cause of Problem	Remedy
Wrong Measurement / Display	Wrong connection	<ul style="list-style-type: none">Check the no. of wires passed through the CT openingCheck the CT selection in common setting menu
Wrong Measurement / Display	Relay is inTrippickup state Motor is running	<ul style="list-style-type: none">Relay will not allow to change any of its setting unless it is healthy state and motor is stoppedThere should not be any pickup & last fault should be acknowledged before editing any setting parameter.Short press RESET for acknowledge the last fault
Protection not getting pickup	Protection is blocked from protection setting menu	Check that the particular protection setting is activated or not.
Output contact not operating	Protection Pickup is Disabled (OFF) Annunciation DO is not assigned Aux Supply not in range	<ul style="list-style-type: none">Check that protection setting for pickup levelCheck DO matrix assignmentVerify the output contact operation via "TRIP TEST"Check aux supply range within specified band only

Sales Offices					
Almudabad 401, Bhp Zavent, Basse-Quatretonic, Alcora Valencia - 46100 Spain Tel : 913237878 / 4252200 E-mail : almudabad@bchindia.com	Bangalore 801, Ashish Deep Building, 2/A, Barahamba Road, New Delhi - 110001 Tel : 011-262281 E-mail : bangalore@bchindia.com	Bhubaneswar Matrix Commercial Complex Plot No. A/10, unit - 3 Bhubaneswar - 751 001 Tel : 0674-2389588 E-mail : bhubaneswar@bchindia.com	Chennai BCC-275, 2nd Floor, Sector-16, Vandalur, Chennai - 601 013 Tel : 0172-507857 / 5049905 E-mail : chennai@bchindia.com	Chennai Flat No. 3A, 3rd Floor, Bharathi Nagar, Chennai - 600 018 Tel : 944337346, 9437347 E-mail : chennai@bchindia.com	Coimbatore 87, Dr. Nanappa Road, Coimbatore - 641 013 Tel : 9423-29511 / 292799 E-mail : coimbatore@bchindia.com
Delhi 1 801, Ashish Deep Building, 2/A, Barahamba Road, New Delhi - 110001 Tel : 011-262281 E-mail : delhi1@bchindia.com	Delhi 2 7/5, Gwalior Building, 92 Nehru Place, New Delhi - 110 019 Tel : 011-4572034 E-mail : delhi2@bchindia.com	Delhi 3 7/5, Gwalior Building, 92 Nehru Place, New Delhi - 110 019 Tel : 011-4572034 E-mail : delhi3@bchindia.com	Faridabad 1/5, Cooperative Industrial Estate, Phase II, Faridabad - 121001 Tel : 0172-507857 / 5049905 E-mail : faridabad@bchindia.com	Hyderabad 1/5, Cooperative Industrial Estate, Phase II, Faridabad - 121001 Tel : 0172-507857 / 5049905 E-mail : hyderabad@bchindia.com	Indore 230/33, Indraprastha Tower, 7/7, Farid Road, Indore - 462 001 Tel : 0771-251011 / 251012 E-mail : indore@bchindia.com
Jaypur 25, Nehru, Gopabari, Jaypur - 302 001 Tel : 0143-25281 E-mail : jaypur@bchindia.com	Jamshedpur A.J. Tower, 2B, 2nd Floor, R.R. Road, Bhatpur, Jamshedpur - 831 001 Tel : 033-2281729 / 4402184 E-mail : jamshedpur@bchindia.com	Kolkata Block 1E, 216, Ashraya Jagadish Chandra Bose Road, Kolkata - 700 011 Tel : 033-2281729 / 4402184 E-mail : kolkata@bchindia.com	Lucknow Shop No. 3, 1st Floor, Tower T-15, Millennium Place B8 - 2, Buddhist Club City, Suburban Road, Lucknow - 226 001 Tel : 0522-4028997 / 4028997 E-mail : lucknow@bchindia.com	Ludhiana Shop No. 3, 1st Floor, Tower T-15, Millennium Place B8 - 2, Buddhist Club City, Suburban Road, Lucknow - 226 001 Tel : 0522-4028997 / 4028997 E-mail : ludhiana@bchindia.com	Mumbai 12, Parvathi Plaza-3rd Floor, 7/7, Farid Road, Indore - 462 001 Tel : 0771-251011 / 251012 E-mail : mumbai@bchindia.com
Mumbai A-101, Mittal Tower, Nariman Point, Mumbai - 400 021 Tel : 022-2282281 / 2289162 Fax : 022-2282281 E-mail : mumbai@bchindia.com	Pune No. 103, 7th Floor, Laxmi Tower, Exhibition Road, Pune - 400 001 Tel : 020-2282281 / 2289162 Fax : 022-2282281 E-mail : pune@bchindia.com	Pune No. 103, 7th Floor, Laxmi Tower, Exhibition Road, Pune - 400 001 Tel : 020-2282281 / 2289162 Fax : 022-2282281 E-mail : pune@bchindia.com	Rajpur 8th Floor, Office No. 807, Bhatpur Capital, Near Dewai Puram, Rajpur - 482 005 Tel : 0771-444563 E-mail : rajpur@bchindia.com	Vadodra 201, 2nd Floor, "Flourance Classic", 10, Ashraya Co-Op. Hsg. Soc. Ltd. Opp. VUDA Housing, Near Civil Circle, Vadodra - 390 005 Tel : 0265-2458662 / 245866 Fax : 0265-245866 E-mail : vadodra@bchindia.com	



BCH Electric Ltd.
20/4, Mathura Road, Faridabad-121006, Haryana
Tel : 0129 4063000/4293000, Fax : 0129-2304016
E-mail: customercare@bchindia.com